



# Florida CirTech, Inc.

1309 North 17th Avenue • Greeley, CO 80631

Telephone: (970) 346-8002 Fax: (970) 346-8331

[www.floridacirtech.com](http://www.floridacirtech.com)

## OMEGA II

### Direct Metallization Processing Steps Vertical Mode

<u>PROCESS STEPS</u>	<u>TEMPERATURE</u>	<u>TIME</u>
1. Cleaner, Conditioner <b>CC-131</b>	60°C to 65°C	5 to 7 minutes
2. Water Rinse	Room Temp	1 to 2 minutes
3. Pre-Dip <b>PD-155</b>	Room Temp	1 to 2 minutes
4. Catalyze <b>CT-160</b>	43°C to 46°C	5 to 7 minutes
5. Water Rinse	Room Temp	1 to 2 minutes
6. Water Rinse	Room Temp	1 to 2 minutes
7. Accelerate <b>AC-171</b>	60°C to 65°C	5 to 7 minutes
8. Water Rinse	Room Temp	1 to 2 minutes
9. 5% Sulfuric Acid	Room Temp	1 to 2 minutes
10. Water Rinse	Room Temp	1 to 2 minutes
11. Water Rinse	Room Temp	1 to 2 minutes
12. Dry & Image or Panel Flash		