

PRECIPITANT WT-FE

GENERAL DESCRIPTION

WT-FE is used to precipitate heavy metal cations including copper, tin, and lead in a batch treatment mode from chelated wastewater and concentrates. WT-FE is a very effective precipitant that normally does not require an additional coagulant, although an anionic flocculent is typically used to facilitate precipitation. When used properly, WT-FE will reduce most heavy metal concentrations to below 1 ppm. Is not well suited for precipitation of nickel bearing wastestreams.

APPLICATION

• WT-FE is used for batch treatment applications and is not suited for flow-through chemical precipitation or micro-filtration applications.

SAFETY AND STORAGE

• Packaging comes in 500-pound cardboard carboys. Consult MSDS sheet for additional information.

PROCEDURE

• 1. Waste solution should be adjusted from initial pH to approximately 1.5 to 2, and allowed to mix for 5 minutes.

• 2. If organics or oxidizers are present, approximately 1 pound of metabisulfite should be added per 100 gallons of waste solution.

- 3. Allow solution to mix for approximately 5 minutes.
- 4. Slowly add WT-FE until an ORP reading of +100 is obtained.
- 5. Allow solution to mix for 10 minutes with ORP reading remaining constant.
- 6. Adjust pH upwards to between 6.5 and 7.5.
- 7. At this point, the ORP reading should be approximately -200 to -250.
- 8. Add approximately 0.1% anionic flocculent to aid solid/liquid separation.

Florida CirTech is a global leader in Advanced Materials and Chemistry. **Visit www.floridacirtech.com for more information.**

Physical Properties

PROPERTIES	
Density	162 lbs per cubic foot
Appearance	Grey/black fine powder
рН	N/A
Odor	None





- 9. Allow solids to settle, then sample supernate for metals content.
- 10. If metals are within limits, decant supernate and send sludge to filter press.

Florida CirTech is a global leader in Advanced Materials and Chemistry. **Visit www.floridacirtech.com for more information.**

